C&JsmartFIRE APP

OPERATION INSTRUCTIONS

CONTENTS

Download the APP and Register an account

1 Download "C&JsmartFIRE" APP.

2 Click "Sign Up".

3 Choose your country. Enter your mobile number or a valid Email address to get verification code.

GET IT ON
Google Play

Download on the
App Store

C&JsmartFIRE

4 Enter the verification code.

5 Set password to complete the registration.

Add device

1 Click "Add Device" or "+".

2 Click "smartFIRE".

3 Select WiFi network and enter the password. Click "Next".

NOTE: Make sure your router is using a 2.4 GHz channel. The distance between the router and fireplace isn't less than 50cm.

4 Turn on the appliance, then press and hold the WiFi button until you hear **3 beeps**. The WiFi indicator and fuel bed start to flash.

5 Choose the EZ Mode, confirm the indicator is flashing and click "Next".

6 Start to add device.

7 Connected when fuel bed becomes in green and stops to flash.

8 Click "Done" to complete pairing.

If the pairing is failed in EZ Mode, please try AP Mode.

9 Press the WiFi button, you will hear **3 beeps**, then keep pressing until you hear other **5 beeps** and the indicator flashes quickly.

10 Choose the AP Mode, confirm the indicator is flashing and click "Next".

11 Click "Go to Connect".

12 Choose a WiFi called "SmartLife-XXX".

13 Go back to the APP. Start to add device.

14 Adding device.

15 Connected when fuel bed becomes in green and stops to flash.

16 Select the right home, click the name of fireplace to enter the homescreen.

Function instructions

FLAME MODE

■ HEATER MODE

NOTE: Only when you set a weekly timer to the flame or heater, the AUTO
mode willl work properly.

■ MY FLAME SELECTION
9 Preset Flame & Fuel bed choices

■ Preset positions 7, 8 & 9 can be reprogrammed to customers own choice

■ FLAME ADJUSTMENT
Allows manual control of flame colour and brightness

■ CRACKLE CHOICE ADJUSTMENT
Allows crackle choice and volume

■ FUEL BED ADJUSTMENT
Allows manual control of fuel bed colour and brightness

■ MOOD LIGHT ADJUSTMENT
This will only operate if optinal mood lights are fitted

■ SET FLAME PROGRAM
Up to 4 time periods a day. 3 different weekly schedules.

■ TEMPERATURE UNIT
  Selects between ℃ or ℉

■ MANUAL HEATING
  ADJUSTMENT

SET HEATER PROGRAM
Up to 4 time periods a day. 3 different weekly schedules.

TIMER

Device information

Virtual ID, IP, Mac, Timer Zone and so on.

Rename your device

1 Click " ✎ ".

2 Click " ✎ ". You can create a new name for your device.

Create a home

1 Click "Home Management".

2 Click "Create a home".

3 Enter home name, select home location and rooms, Click "Save".

Add member

4 Click "Done", the home successfully created.

1 Select "Me" → "Home Management" → "Name of Home" → "Home Settings". Select "Add Member".
NOTE: DownLoad the APP for your new member firstly.

2 Select 1: "APP account".
NOTE: It's the new member's account, not your own's.

3 Select "Others" to get invitation code. Then go to "Me > Home Management > Join Home" and enter the code. Select the Home and ready for operate the appliance.

Share device

1 Click " ✎ ".

2 Click "Share Device".

3 Click "Add Sharing".

4 Read the tip and click "Confirm".   **5** Input an account and click "Done".